

## **GR39 TRU-TURF EQUIPMENT NOV '04**

<b>Number</b>	<b>SPARE PARTS LIST</b>	<b>Use</b>
G4000	Main Body	
G4001	Transmission Cover; Hinge Type	
G4002	Seat Frame	
G4003	Seat Base	R5003
G4004	Seat Base Pin	R5004
G4005	Arm Rest Support	R5005
G4006R	Arm Rest RH	R5006R
G4006L	Arm Rest LH	R5006L
G4007	Seat	R5007
G4008	Joystick	R5008
G4009	Hand Grip	R5009
G4010	Bearing 6304	R5010
G4011	Foot Pedal	R5011
G4012	Foot Pedal Pad	R5012
G4013	Cover Pin	R5015
G4014	Cover Catch (includes pin & Hook)	R5016
G4015	Sticker (Safety Sticker Pack)	N/A
G4016RH	Trailer Arm RH	R5018R
G4061LH	Trailer Arm LH	R5018L
G4017	Drawbar (Pin type)	R5019
G4018	Drawbar (50mm Ball Coupling)	R5020
G4019	Catch, Front Trailer	R5102
G4020	Spring	R5049
G4021	Catch; Trailer Up	R5023
G4022	Spring; Trailer Up (Heavy)	R5022
G4023	Trailer Plastic Plug Kit	N/A
G4024	Hydraulic Strut - Spec 090402Q0 - Roller	R5026 Retro
G4025	Tyre & Rim	R5027
G4026	Bearing 6205	R5028
G4027	Engine Honda (4hp 2:1 reduction)	R5029
G4028	Coupling, Honda Engine 4hp	R5030
G4031	Rubber Coupling	R5031
G4032	Transmission Coupling Eaton 7	R5032
G4033	Fan	R5033
G4034	Transmission Eaton 7	R5034
G4035	Sprocket 11T + 1/8" Woodruff Key & 5/16" Allen Screw	R5035
G4036	Chain & Joiner	R5036
G4037	Sprocket 30T	R5039
G4037A	Taper Lock 30 mm	R5039A
G4038	Sprocket Assy; Simplex; 12Tooth; Inc. R5050 Bearing; R5188 Sprocket; R5180 Circlip & R5183 Circlip	R5037
G4039	Tensioner Arm	R5038
G4039A	Tensioner Arm	R5038
G4040	Nylon Bush (G.C. shocky)	N/A
G4040A	Nylon Bush (G.C. shocky)	N/A
G4041	Capped Washer 1/2"	R5041
G4042	Spring - Ext. 90mm x 13mm x 1.5mm	R5094
G4043	Bracket; Transmission; Eaton 7	R5043
G4044	Lever; Neutral; For Eaton 7 Transmission	R5044
G4045	Yoke; Eaton 7 Transmission; To Suit R5048 Self-Centring Arm	R5045
G4046	Rod (inc. 2 x Rod Ends)	R5046
G4047	Arm; Foot Pedal; for Eaton 7	R5047
G4048	Self Centring Kit	R5048
G4049	Bush Nylon	R5075
G4050	Bearing; 6000	R5050
G4051	Strut; Transmission; Spec-081200Q0; To Suit R5048 Self-Centring Arm	R5051
G4052	Nylon Bush (Fit new mod. Kit R5038A)	
G4053	Drive Roller	G7001

G4054	Woodruff Key 8x7x30mm	R5087
G4055	Housing; LFL5J; F205;2 Hole; For R5070 B5 Bearing	R5068
G4056	Housing; F205; LF205 4 Hole; For R5070 B5 Bearing	R5067
G4057	Bearing; B5;25MM	R5070
G4058	Mud Flap Strap	R5061
G4059	Mud Flap	R5071
G4060	Arm;Steering;GR39	R5072
G4061	Kit;Steering Connecting Rod, inc 1xG4062 Rod;2xR5118 Rod Ends;2 x 3/8" Nuts	R5073
G4062	Rod;Steering Connecting	R5185
G4063	Key - Transmission	R5090
G4064	Bearing; 6000	R5050
G4065	Smoothing Head	
G4066	Smoothing Head Spacer	
G4067	Smoothing Head Bearing Carrier	
G4068	Tube; Smoothing Head;1012mm x 60mm OD	
G4069	Shaft; 20mm	
G4071	Mats - Foot	R5088
G4072	Key	R5089
G4073	Shim Engine Honda 1,2 or 3 mm thick	R5085
G4075	Shaft;Stepped from 25mm to 20mm for Smoothing Roller	
G4076	Transmission Cover; 2 Catch Type	
G4077	Kit;Scraper;Wire;Set of 3 x 1032mm;for Smoothing Roller	
G4078	Red Bracket for Kit G4080 & G4081	
G4079	Yellow Bracket for Kit G4080	
G4080	Kit; Trailer Arm Strut & Catch Replacement; GR39 Only; Incl. 1xG4078 Red Bracket;1xG4079 Yellow Bracket.See Trailer Strut Identification Picture # 2	
G4081	Yellow Bracket for Kit G4082	
G4082	Kit;Trailer Arm Strut & Catch Replacement;GR39 only;inc. 1xG4078 Red Bracket;1xG4081 Yellow Bracket. See Trailer Strut Identification Picture # 1	
G4083	Kit; Smoothing Roller;GR39;inc. 1xG4075 Shaft; 1xG4068 Tube; 2xR5010 Bearings; 2xR5103 Flat Washers;2 x R5208 Bolts; 2 x R5209 Spring washers	
R39134-A	Transmission 700-003 Eaton	R5034
R39135-A	Coupling;Engine;Vanguard (B&S);Eaton Transmission	
R39139-A	30Tooth Simplex Sprocket	R5039
R39158-A	11 Tooth Simplex Sprocket (Eaton Trans. Only)	R5035
R39159-A	Key Woodruff (Eaton Transmission only)	R5090
R39185	Engine Honda	R5029
R39206	Transmission Mount (Eaton Transmission)	R5043
R39208	Coupling; Eaton 7 Transmission - Honda 4 HP Engine	R5032
R39209	Centring Plate Adjustor (Eaton Transmission)	R5116
R39210	Centring Arm (Eaton Transmission)	R5048
R39211	Transmission Control Arm (Eaton Trans)	R5045
R39213	Chain Adjustor LH	R5038
R39214	Chain Adjustor RH	R5038
R39215	Nylon Bush Chain Adjustor. Not Avail. Supply R5038 Kit	R5038 kit
R39216	Bearing; 6000	R5050
R39217	Sprocket 12 tooth Simplex	R5037
R5003	Plate; Seat Base	
R5004	Pin; Seat Base	
R5005	Bracket; Arm Rest Support	
R5006L	Rest; Arm; LH	
R5006R	Rest; Arm; RH	
R5007	Seat; Pan; P2 incl 3 Cleats	
R5008	Joystick	
R5009	Grip; Hand; Joystick	
R5010	Bearing; 6304	
R5012	Pad; Rubber; Foot Pedal	
R5015	Pin; Cover; Transmission	
R5016	Rubber part;Catch; Cover; Transmission & Seat	
R5021	Catch; Drawbar; With Tab; For R5049 Spring	
R5022	Spring; Trailer Up	
R5023	Catch; Trailer Up	
R5026	Strut; Hydraulic;Obsolete;See Identification Chart & Supply R5210 Strut + correct kit	

R5027	Tyre & Wheel Complete	
R5028	Bearing; 6205;25 ID 52 OD To Suit R5027 Wheel & R6042 Smoothing Tube	
R5029	Engine; Honda 4HP; GX120; LX2; LXU 2:1 reduction	
R5030	Coupling; Honda 4 HP Engine	
R5031	Coupling;Rubber	
R5032	Coupling; Eaton 7 Transmission;Honda 4.OHP	
R5033	Fan	
R5034	Transmission; Eaton 7	
R5035	Sprocket;Simplex; 11T & 1/8" Woodruff key	
R5036	Chain; Simplex; Eaton 7 Transmission;incl R5036A Joiner	
R5036A	Connecting Link; Joiner; Simplex; Chain	
R5037	Sprocket Assy; Simplex; 12Tooth; Inc. R5050 Bearing;R5188 Sprocket; R5180 & R5183 Circlips	
R5038	Arm; Chain Tensioner;One Only	
R5038 kit	Tensioner Kit; Chain; Replacement for early Chain Tensioner Arms with Steel or Nylon Bushes. Comprises 2 x R5038 Chain Tensioner Arms; 2 x R5037 Sprocket Assemblies; 2 x R5099 Bronze Bushes; 1 x R5094 Spring; 1 x R5101 Sizing Sleeve; 1 x R5041 Capped Wash	
R5039	Sprocket; 30 Tooth; Drive Roller; Eaton 7	
R5039A	Bush, Taper Lock; 30mm;2012;for R5141 Sprocket 27 Tooth	
R5040	Bush; Steel; Obsolete; Supply R5038 kit (1 x Kit for each 2 R5040 ordered)	
R5041	Washer; Capped; 1/2"	
R5042	Spring; Chain Tensioner; Superseded by R5094 Spring	
R5043	Bracket; Transmission; Eaton 7	
R5044	Lever; Neutral; For Eaton 7 Transmission	
R5045	Yoke; Eaton 7 Transmission; To Suit R5048 Self-Centring Arm	
R5046	Rod Unit; Arm;Foot Pedal-Yoke;Transmission inc.1 x R5184 Rod; 2 x R5118 Rod Ends; 2 x 3/8" Nut	
R5047	Arm; Foot Pedal;for Eaton 7	
R5048	Arm; Self Centring	
R5049	Spring; Steering Return & Catch	
R5050	Bearing; 6000	
R5051	Strut; Transmission; Spec-081200Q0; To Suit R5048 Self-Centring Arm	
R5052	Bush; Nylon; Black; Use R5075	
R5061	Strap; Mud Flap	
R5067	Housing; F205; LF205 4 Hole; For R5070 B5 Bearing	
R5068	Housing; LFL5J; F205;2 Hole; For R5070 B5 Bearing	
R5070	Bearing; B5;25MM	
R5071	Mudflap 150mm X 160mm	
R5075	Bush; Nylon; Black; 27x16.9x32mm	
R5085-1	Shim;1mm Thick; Honda Engine	
R5085-2	Shim;2mm Thick; Honda Engine	
R5085-3	Shim;3mm Thick; Honda Engine	
R5087	Key; Woodruff; 8mm x 30mm	
R5088	Mat; Foot 300 x 180 x 3 Ribbed; Adhesive	
R5089	Key; Woodruff; 3/16"; For Joystick prior to "B" Series & in Eaton 11 Trans Coupling	
R5090	Key; Woodruff; 1/8" x 1/2"; For Eaton 7 Transmission,Yoke & R5035 Sprocket	
R5091	Engine; 5.5 HP; Honda; GX160 LX2;LX4;LXU	
R5093	Spring; Coil; Drawbar	
R5094	Spring; Arm;Chain Tensioner;90mm x 13mm x 1.5mm	
R5099	Bush; Bronze; For Chain Tensioner Arms	
R5102	Catch; Front Trailer; No Spring Tab; Use R5093 Spring	
R5103	Washer; 20 x 42 x 3mm; Fits Smoothing Roller Shafts R5106 & G4075	
R5107	Ball Fitting; Strut; Trailer/Roller; 13mm Dia. M10 Thread	
R5108	Ball Fitting;Small Flange;Strut; Foot Pedal; 10mm Dia. M8 Thread	
R5109	Retainer; Clip; For R5115 Strut Cup End 13mm	
R5110	Ball Fitting; Strut; Trailer Roller; 13mm Dia. M8 Thread	
R5111	Retainer; Clip; For R5114 Strut Cup End 10mm	
R5112	Circlip; External; 25mm	
R5113	Washer; Flat; 24x44x2mm;Suits only R5028 Bearing	
R5114	Cup End; Standard;Strut; 10mm Dia. Ball; Foot Pedal	
R5115	Cup End; Strut; 13mm Dia. Ball; For Trailer/Roller	
R5116	Support; Self-Centring Arm	
R5118	Rod End; 3/8" UNF; For Threaded Rod (part Rod Units R5084;R5046;R5073)	
R5119	Light; 3" x 5"; 50 Watt	

R5120	Coil; Lighting; ZEI 711; For Honda 4HP & 5.5 HP	
R5121	Flywheel; Honda 5.5 HP; ZEI 811	
R5122	Bolt; Flange; 6 x 28; Coil; 883 000	
R5123	Switch; Light	
R5124	Harness; Wire; Incl. Tube	
R5125	Bracket; Lights; For Light Kit	
R5126	Bracket; Switch; For Light Kit	
R5127	Light Kit; Optional	
R5128	Bracket; Hour/Tach Meter	
R5129	Meter; Hour/Tach	
R5134	Arm; Self-Centring; Obsolete; To Suit R5161 Bearing 6200	
R5135	Yoke; Transmission; Used With R5134 Self-Centring Arm	
R5155	Bush; Taper Lock; 30mm; Use R5039A	R5039A
R5158	Rubber Strip; Frame; Seat	
R5159	Rubber Strip; Rest; Trailer	
R5164	Woodruff Key 4 x 6.5mm	
R5166	Flywheel; Honda 4.0 HP; ZEO 811	
R5179	Ball Fitting; Large Flange; 13mm; M8 Thread	
R5180	Circlip; External; 10mm	
R5182	Circlip External 1/2" 12.5mm	
R5183	Circlip Internal 1.0" 25.4mm	
R5184	Rod; 3/8" x 70mm; Connects Foot Pedal Arm To Transmission Yoke	
R5186	Rod; 3/8" x 205mm; Connects Steering Arm To Smoothing Head; GR39	
R5188	Sprocket Only; 12Tooth; Supply R5037 Sprocket Kit	R5037
R5195	Key; 32.5mm x 5mm x 5mm; Honda/Kohler Engines	
R5208	Bolt; 3/8"x1" UNF Hex Head	
R5209	Washer; 3/8" Spring	
R5212	Nut; 3/8" UNF	
R5213	Clip; Steel; Pinch Cleat; Seat	
R5215	Kit; Progressive Transmission & Foot Pedal Self-Centring; GR/RS Eaton 7; Incl. 1 x R5172 Yoke; 2 x R5173 Strut Kits	
R6040	Sticker; Sloping Greens	
R6041	Sticker; Danger, Cover Removal	